

iPad mini・iPad・iPod修理メニュー
税込価格です。

機種名/症状	ガラス破損	ガラス+液晶	バッテリー	インカメラ	アウトカメラ	ホームボタン	ボタンSW	ドックコネクタ	イヤースピーカー	外部スピーカー	パイプ	機種名/症状
iPad 1st	15,180	21,780	14,080	11,880	11,880	12,100	12,980	15,180		12,980	12,100	iPad 1st
iPad 2nd	14,080	20,680	14,080	11,880	11,880	12,100	12,980	15,180		12,980	12,100	iPad 2nd
iPad 3rd / 4th	14,080	21,780	14,080	11,880	11,880	14,080	12,980	15,180		12,980	14,080	iPad 3rd / 4th
iPad 5th 2017	16,280	22,880	14,080	14,080	14,080	14,080	12,980	15,180		12,980	14,080	iPad 5th 2017
iPad 6th 2018	18,480	25,080	14,080	14,080	14,080	14,080	12,980	16,280		12,980	14,080	iPad 6th 2018
iPad 7th 2019	21,780	37,180										iPad 7th 2019
iPad Air	15,180	20,680	14,080	14,080	14,080	14,080	14,080	15,180		12,980	14,080	iPad Air
iPad Air2	27,280	27,280	14,080	12,980	14,080	14,080	17,380	16,280		16,280	19,580	iPad Air2
iPad Air3	34,980	34,980	19,580	16,280		16,280		19,580				iPad Air3
iPad mini	15,180	19,580	14,080	11,880	11,880	12,980	12,980	15,180		12,980	12,980	iPad mini
iPad mini2	15,180	21,780	14,080	11,880	11,880	12,980	12,980	15,180		12,980	12,980	iPad mini2
iPad mini3	15,180	21,780	14,080	14,080	14,080	14,080	14,080	15,180		12,980	14,080	iPad mini3
iPad mini4	25,080	27,280	14,080	12,980	14,080	14,080	17,380	16,280		16,280	19,580	iPad mini4
iPad mini5	32,780	32,780	16,280	16,280		14,080	19,580	16,280				iPad mini5
iPad Pro 9.7	29,480	29,480	16,280	15,180	17,380	16,280	16,280	19,580		16,280	19,580	iPad Pro 9.7
iPad Pro 10.5	34,980	34,980	16,280	17,380	17,380	16,280	21,780	21,780		19,580	23,980	iPad Pro 10.5
iPad Pro 11	59,180	59,180	23,980				21,780	23,980				iPad Pro 11
iPad Pro 11 2nd	59,180	59,180					26,180					iPad Pro 11 2nd
iPad Pro 12.9 1st	38,280	37,180	19,580	15,180	16,280	19,580	17,380	27,280		19,580	19,580	iPad Pro 12.9 1st
iPad Pro 12.9 2nd	60,280	60,280	20,680	16,280	17,380	19,580	21,780	27,280		19,580	23,980	iPad Pro 12.9 2nd
iPad Pro 12.9 3rd	56,980	56,980	23,980					23,980				iPad Pro 12.9 3rd
iPad Pro 12.9 4th	56,980	56,980						27,280				iPad Pro 12.9 4th
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	インカメラ	アウトカメラ	ホームボタン	ボタンSW	ドックコネクタ	イヤースピーカー	外部スピーカー	パイプ	機種名/症状
iPod Touch 1st	14,080	14,080	12,980			15,180	15,180	15,180	12,540			iPod Touch 1st
iPod Touch 2nd / 3rd	14,080	14,080	12,980			13,420	15,180	15,180	12,540	12,650		iPod Touch 2nd / 3rd
iPod Touch 4th	12,980	12,980	11,880	12,650	11,550	14,080	11,880	11,880	13,420	12,650		iPod Touch 4th
iPod Touch 5th	15,180	15,180	11,880	11,550	14,080	15,180	12,980	12,980	12,540	12,650		iPod Touch 5th
iPod Touch 6th / 7th	15,180	15,180	11,880	11,550	14,080	15,180	16,280	16,280	13,420	12,650		iPod Touch 6th / 7th
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	インカメラ	アウトカメラ	ホームボタン	ボタンSW	ドックコネクタ	イヤホンジャック	外部スピーカー	パイプ	機種名/症状
iPod mini1	21,780	21,780	26,180					16,280				iPod mini1
iPod mini2	16,280	16,280	26,180					11,880				iPod mini2
iPod nano 1	19,580	19,580	23,100				14,300	10,780				iPod nano 1
iPod nano 2	21,780	21,780	23,100				12,650	10,780				iPod nano 2
iPod nano 3	16,280	16,280	16,280				12,650	12,980				iPod nano 3
iPod nano 4	15,180	15,180	16,280				12,650	12,980	12,980			iPod nano 4
iPod nano 5	15,180	15,180	12,980		12,650		12,650	12,980	12,980	13,420		iPod nano 5
iPod nano 6	15,180	15,180	12,980					14,080	14,080			iPod nano 6
iPod nano 7	15,180	15,180	14,080			10,450	12,650	14,080	14,080			iPod nano 7
iPod nano 7 Mid	15,180	15,180	14,080			10,450	12,650	14,080	14,080			iPod nano 7 Mid
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	インカメラ	アウトカメラ	センターボタン	スクロールホイール	ドックコネクタ	イヤホンジャック	外部スピーカー	パイプ	機種名/症状
iPod 1	19,580	19,580	21,780			18,700	18,700	19,580	14,520			iPod 1
iPod 2	16,280	16,280	21,780			15,400	15,400	18,480	14,520			iPod 2
iPod 3	16,280	16,280	21,780			17,600	17,600	18,480	14,520			iPod 3
iPod 4	12,980	12,980	23,980			14,520	14,520	19,580	14,520			iPod 4
iPod Photo	14,080	14,080	14,080			14,520	14,520	21,780	12,100			iPod Photo
iPod Video	15,180	15,180	14,080			14,520	14,520	16,280	12,980			iPod Video
iPod Classic	15,180	15,180	14,080			14,520	14,520	16,280	12,980			iPod Classic