

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
14ProMax	69,900	16,900		19,900	27,900	7,000	22,000	
14Pro	64,900	15,900		19,900	22,900	7,000	20,000	
14Plus	23,900	16,900		23,000	22,900	7,000	19,000	
14	21,900	16,900		23,000	22,900	7,000	18,000	
13ProMax	30,900	11,900		23,500	24,900	6,000	11,900	16,000
13Pro	29,900	10,900		21,500	23,900	6,000	11,900	15,000
13	17,900	9,900		19,000	16,900	6,000	11,900	14,000
13mini	17,900	9,900		19,000	16,900	6,000	11,900	13,000
SE3	9,900	4,900	4,900	7,700	9,900	3,500	7,900	
12ProMax	18,900	6,900		16,900	17,900	5,000	8,900	11,000
12Pro / 12	16,900	6,900		15,900	17,900	5,000	8,900	11,000
12mini	17,900	6,900		15,900	12,900	5,000	8,900	11,000
SE2	5,900	3,500	4,900	6,900	8,900	3,300	7,000	6,600
11ProMax	13,900	4,900		12,900	15,900	4,500	8,500	6,600
11Pro	11,900	4,900		12,900	14,900	4,500	7,900	6,600
11	9,900	4,900		9,900	11,900	4,500	7,900	6,600
XR	9,900	4,900		7,700	11,900	3,900	7,900	6,600
XSMAX	11,900	4,900		7,700	12,900	3,900	7,900	6,600
XS	9,900	4,900		7,500	12,900	3,900	7,900	6,600
X	8,900	4,900		7,000	10,900	3,900	7,900	6,600
8Plus	6,500	3,300	3,900	6,600	9,900	2,900	5,500	3,900
8	5,500	3,300	3,900	6,400	6,900	2,900	5,500	3,900
7Plus	4,900	3,300	3,900	4,900	7,900	2,900	3,900	3,500
7	4,500	3,300	3,900	4,400	4,900	2,900	3,900	2,900
6sPlus	4,300	2,980	2,500	3,850	4,500	2,900	2,900	2,900
6s	3,900	2,980	2,500	3,850	3,900	2,900	2,900	2,900
6Plus	3,900	2,980	2,500	3,850	3,500	2,900	2,900	2,900
6	3,500	2,980	2,500	3,850	3,500	2,900	2,900	2,900
SE	3,700	2,980	2,500	3,850	3,500	2,900	2,900	2,900
5 / 5s / 5c	3,500	2,980	2,500	3,850	3,500	2,900	2,900	2,500
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：0円(復旧しない場合は費用はかかりません。)							
	成功費：5,500							

消費税込みの表記です。