

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
14Plus	28,900	11,900				9,000		
14	28,900	11,900				9,000		
SE3	6,900	3,900	8,900	11,000		9,000		
13	24,900	10,900			21,900	9,000	11,900	12,000
13mini	24,900	10,900			21,900	7,000	13,900	12,000
12ProMax	19,900	8,900			24,900	6,900	11,900	11,000
12Pro / 12	17,900	8,900			24,900	6,900	10,900	11,000
12mini	17,900	8,900			17,900	6,900	10,900	11,000
SE2	6,900	3,900	8,500	7,000	15,000	6,000	11,000	10,000
11ProMax	16,900	6,900		21,000	21,000	6,000	16,000	12,000
11Pro	15,900	6,900		21,000	21,000	6,000	16,000	12,000
11	11,900	6,900		16,000	19,000	6,000	16,000	12,000
XR	8,900	5,900		8,500	12,000	5,000	8,500	8,000
XSMAX	14,900	6,500		10,000	15,500	5,000	11,000	9,000
XS	9,900	5,900		9,500	15,000	5,000	10,000	8,500
X	8,900	4,900		8,500	13,000	5,000	9,000	8,000
8Plus	6,900	3,900	8,500	6,500	13,000	4,000	8,000	6,500
8	6,900	3,900	8,500	6,000	11,000	4,000	7,500	6,500
7Plus	6,900	3,900	8,500	6,000	12,000	3,000	6,000	6,500
7	5,900	2,900	8,500	6,000	8,000	3,000	6,000	6,500
6sPlus	5,900	2,900	4,500	5,500	6,000	3,000	4,500	4,500
6s	5,900	2,900	4,500	5,500	6,000	3,000	4,500	4,500
6Plus	5,900	2,900	3,000	5,500	6,000	3,000	3,000	3,000
6	5,900	2,900	3,000	5,500	6,000	3,000	3,000	3,000
SE	5,900	2,900	3,000	5,500	6,000	3,000	3,000	3,000
5 / 5s / 5c	5,900	2,900	3,000	5,500	6,000	3,000	3,000	3,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：2,000							
	成功費：5,000							

消費税込みの表記です。