

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
SE3	6,900		8,900	9,000	14,500	5,500	10,000	9,000
13	27,900				24,000	7,000	19,000	
13mini	26,900				24,000	7,000	18,000	
12ProMax	19,900							
12Pro / 12	17,900							
12mini	16,900							
SE2	3,900	2,900	8,500		13,000	3,500	9,000	8,000
11ProMax	10,900	4,900			19,000	5,500	14,000	
11Pro	7,900	4,900			19,000	5,500	14,000	
11	6,900	4,400			17,000	5,500	14,000	
XR	5,900	3,900		7,500	11,000	5,500	7,500	7,000
XSMAX	7,900	3,900		9,000	14,500	5,500	10,000	8,000
XS	5,900	3,900		8,500	14,000	5,500	9,000	7,500
X	5,900	3,900		7,500	12,000	5,500	8,000	7,000
8Plus	4,900	2,900	8,500	5,000	12,000	3,500	7,000	5,500
8	3,900	2,900	8,500	5,000	12,000	3,500	7,000	5,500
7Plus	4,900	1,900	8,500	5,000	10,000	2,500	6,500	5,500
7	3,900	1,900	8,500	4,500	11,500	2,000	5,000	5,500
6sPlus	3,900	1,900	8,500	5,500	7,000	2,000	5,000	5,500
6s	3,900	1,900	4,500	2,500	5,500	2,000	3,500	3,500
6Plus	3,900	1,900	4,500	2,500	5,500	2,000	3,500	3,500
6	3,900	1,900	3,500	2,500	5,500	2,000	2,000	2,000
5 / 5s / 5c	2,900	1,900	3,500	2,500	3,500	2,000	2,000	2,000
SE	2,900	1,900	3,500	2,500	5,500	2,000	2,000	2,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：3,900							
	成功費：4,900							

消費税込みの表記です。