

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15Plus	49,000					9,000		
15	48,000					9,000		
14Plus	21,900					8,000		
14	19,900					8,000		
SE3	6,500	3,900	6,500	9,000	10,000	3,000	6,000	6,500
13	19,900	7,900		21,000	23,000	7,000	17,000	14,000
13mini	19,900	7,900		19,000	22,000	7,000	16,000	13,000
12ProMax	16,900	5,900		17,000	17,000	5,000	15,000	12,000
12Pro	14,900	5,500		17,000	17,000	5,000	15,000	12,000
12	14,900	5,500		16,000	17,000	5,000	14,000	11,000
12mini	15,900	5,500		15,000	14,000	5,000	13,000	10,000
SE2	4,500	2,900	5,500	8,000	9,000	3,000	5,500	6,000
11ProMax	13,900	5,500		14,000	13,500	3,000	12,500	9,500
11Pro	11,900	5,500		13,000	12,500	3,000	11,500	9,000
11	10,900	4,900		12,500	10,500	3,000	10,500	8,500
XR	9,900	3,900		7,000	10,000	3,000	8,500	6,500
XSMAX	10,900	3,900		8,000	11,500	3,000	10,000	7,000
XS	9,900	3,900		7,500	11,000	3,000	8,500	6,000
X	8,500	3,900		7,500	10,500	3,000	8,000	5,500
8Plus	4,500	2,900	5,000	7,000	11,550	3,000	5,500	4,500
8	4,500	2,900	5,000	7,000	9,000	3,000	5,000	4,500
7Plus	4,500	2,900	4,500	6,500	10,500	3,000	5,000	4,000
7	4,500	2,900	4,500	6,500	8,000	3,000	4,500	4,000
6sPlus	3,500	2,900	4,000	4,500	4,000	3,000	3,000	3,000
6s	3,500	2,900	4,000	4,500	4,000	3,000	3,000	3,000
6Plus	3,500	2,900	3,500	4,500	4,000	3,000	3,000	3,000
6	3,500	2,900	3,500	4,500	4,000	3,000	2,500	3,000
SE/5 / 5s / 5c	3,500	2,900	3,000	4,500	4,500	3,000	2,500	3,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：無料 復旧が成功しない限り費用はいただきません。							
	成功費：7,000							



消費税込みの表記です。