

修理パーツ	パネル			バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
	液晶	A品 / GXOLED	有機EL (純正同等)				アウト	レンズ	イン	
SE3	7,900			6,500			14,400	6,500	9,900	9,900
13	34,900			8,900			24,900	7,900	18,900	12,900
13mini	34,900			8,900			23,900	7,900	17,900	12,900
12ProMax	30,900	+8,900		7,900			22,900	6,500	16,900	12,900
12Pro / 12	26,900	+7,900		7,900			22,900	6,500	15,900	11,900
12mini	25,900	+7,900		7,900			15,900	6,500	14,900	11,900
SE2	5,900	+2,900		4,500	7,900	9,900	14,400	6,500	9,900	9,900
11ProMax	22,900	+8,900	+16,500	7,000		17,900	17,900	5,900	14,900	12,900
11Pro	19,900	+6,900	+8,900	7,000		16,900	17,900	5,900	13,900	12,500
11	12,900			6,500		14,900	14,900	5,900	13,900	11,900
XR	10,900			5,000		11,900	14,900	5,900	11,900	10,500
XSMAX	19,900	+6,900	+12,900	6,000		12,900	16,900	5,900	12,900	11,500
XS	11,900	+4,900	+8,900	5,500		12,900	15,900	5,900	12,900	10,900
X	10,900	+3,900	+6,900	4,400		11,900	12,900	5,900	11,900	9,900
8Plus	6,900	+2,500		3,900	7,900	7,900	14,900	4,900	10,900	7,900
8	5,900	+2,500		3,900	7,900	7,900	11,900	4,900	9,900	7,900
7Plus	6,500	+2,500		3,500	6,900	6,900	10,900	4,900	8,900	7,900
7	4,900	+1,900		2,900	6,900	6,900	9,900	4,900	7,900	7,900
6sPlus	4,500			2,900	5,900	6,500	7,900	4,900	5,900	5,900
6s	4,500			2,500	5,900	6,500	7,900	4,900	5,900	5,900
6Plus	4,500			2,500	4,900	5,900	5,900	4,900	4,900	5,900
6	4,500			2,500	4,900	5,900	5,900	4,900	4,900	5,500
SE / 5s	3,900			2,500	3,900	4,500	6,900	4,900	4,900	5,500
5 / 5c	2,900			2,500	3,900	4,500	5,900	4,900	4,900	4,900
修理パーツ	液晶	A品 / GXOLED	有機EL (純正同等)	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
	パネル						カメラ			
<b>修理作業費</b> 1台ごとに必要です。	2,000									
<b>水没復旧</b> 修理作業費込の金額です。	受付費：3,300									
	成功費：7,700									