

修理パーツ	パネル			バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
	液晶	A品 / GXOLED	有機EL (純正同等)				アウト	レンズ	イン	
SE3	8,360			6,600						
14ProMax	80,850			16,830						
14Pro	74,800			15,400						
14Plus	33,880			14,410						
14	32,890	+ 8,800		13,200						
13ProMax	68,860			9,900						
13Pro	59,840			8,800						
13	25,300	+ 8,800		9,680						
13mini	26,840	+ 7,150		8,800						
12ProMax	21,890	+ 6,600		8,690						
12Pro / 12	16,830	+ 6,600	8,800	8,030						
12mini	18,370	+ 6,600		8,800						
SE2	5,830	+ 2,750		3,850		9,900	13,200	6,050	9,900	10,450
11ProMax	12,870	+ 5,500	+ 9,900	6,710		18,480	18,150	6,050	17,050	13,750
11Pro	11,880	+ 5,500	+ 8,800	6,600		16,500	17,050	6,050	15,950	13,200
11	10,890			6,380		14,850	14,850	6,050	14,850	12,100
XR	9,900			4,070		11,000	14,300	6,050	11,000	10,450
XSMAX	11,880	+ 5,500	+ 11,000	5,500		12,650	18,150	6,050	13,200	11,550
XS	9,900	+ 3,850	+ 7,150	4,840		12,100	17,600	6,050	12,650	11,000
X	9,900	+ 3,850	+ 7,150	4,290		11,000	15,400	6,050	11,550	10,450
8Plus	5,830	+ 2,530		3,850	8,800	8,800	15,400	4,950	10,450	8,800
8	5,390	+ 2,200		3,630	8,800	8,800	13,200	4,950	9,900	8,800
7Plus	6,380			3,300	7,150	7,150	14,850	4,950	8,250	8,800
7	4,840			3,190	7,150	7,150	10,450	4,950	8,250	8,800
6sPlus	4,180			3,080	6,600	6,600	8,800	4,950	6,600	6,600
6s	4,180			3,080	6,600	6,600	8,800	4,950	6,600	6,600
6Plus	4,180			2,860	6,600	6,600	8,800	4,950	5,500	5,500
6	3,300			2,860	6,600	6,600	6,600	4,950	5,500	5,500
SE / 5s	3,190			2,090	6,600	6,600	8,800	4,950	5,500	5,500
5 / 5c	3,080			1,870	6,600	6,600	6,600	4,950	5,500	4,400
修理パーツ	液晶	A品 / GXOLED	有機EL (純正同等)	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
	パネル						カメラ			

<b>修理作業費</b> 1台ごとに必要です。	2,200
<b>水没復旧</b> 修理作業費込の金額です。	受付費：3,300 成功費：7,700

消費税込みの表記です。