

iPad修理メニュー

※全て税込・作業費込価格です。

機種名/症状	ガラス破損	ガラス+液晶	バッテリー	ドックコネクタ	インカメラ	アウトカメラ	ホームボタン	ボタンSW	外部スピーカー
1st	17,600	24,600	16,600	17,100	15,400	15,400	15,600	16,600	16,600
2nd 3rd	16,600	20,600	16,600	17,100	15,400	15,400	15,600	16,600	16,600
4th	17,600	20,600	16,600	17,100	15,400	15,400	15,600	16,600	16,600
5th 2017 6th 2018	19,100	27,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
7th 2019 8th 2020	19,600	27,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
9th 2021	20,600	28,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
10th 2022	21,600	41,600	17,600	18,600	18,600	18,600	3,000	16,600	16,600
Air	17,600	25,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
Air2	29,600	29,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
Air3	32,600	32,600	17,600	18,600	17,600	17,600	15,600	21,600	21,600
Air4	34,400	34,400	18,600	18,100	17,600	17,600	3,000	17,600	17,600
Air5	34,400	34,400	18,600	18,100	17,600	17,600	3,000	19,600	19,600
mini	17,600	21,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
mini2	17,600	23,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
mini3	18,100	23,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
mini4 mini5	28,600	28,600	16,600	17,100	17,100	17,100	15,600	16,600	16,600
mini6	50,600	50,600	18,600	18,100	18,100	18,100	3,000	18,600	18,600
Pro 9.7	31,600	31,600	17,600	18,600	18,600	18,600	15,600	19,600	19,600
Pro 10.5	32,600	32,600	19,100	18,600	18,600	18,600	15,600	21,600	21,600
Pro 11 1st 2nd / 3rd / 4th	40,600	40,600	19,100	18,100	18,100	18,100	3,000	17,600	17,600
Pro 12.9 1st	41,600	41,600	19,100	19,100	19,100	19,100	16,600	19,600	19,600
Pro 12.9 2nd	67,600	67,600	19,100	19,100	19,100	19,100	16,600	19,600	19,600
Pro 12.9 3rd / 4th	40,600	40,600	19,100	18,100	18,100	18,100	3,000	19,100	19,100
Pro 12.9 5th / 6th	52,600	52,600	21,600	18,100	18,100	18,100	3,000	23,600	23,600
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	ドックコネクタ	インカメラ	アウトカメラ	ホームボタン	ボタンSW	外部スピーカー