

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15Plus	48,500 (事前予約でパーツ発注)					4,000		
15	47,500 (事前予約でパーツ発注)					4,000		
14ProMax	73,000 (事前予約でパーツ発注)	11,500		16,000	15,000	3,000	11,000	8,000
14Pro	63,000 (事前予約でパーツ発注)	11,500		16,000	15,000	3,000	11,000	8,000
14Plus	29,500	9,500		12,500	14,000	3,000	11,000	8,000
14	26,500	9,500		10,500	14,000	3,000	11,000	8,000
SE3	5,000	4,000	5,500	6,500	7,500	3,000	5,500	5,500
13ProMax	47,500 (事前予約でパーツ発注)	7,500		15,000	14,000	3,000	9,500	7,500
13Pro	38,000 (事前予約でパーツ発注)	7,500		15,000	14,000	3,000	9,500	7,500
13	19,500	6,000		9,500	12,500	3,000	9,500	7,500
13mini	19,500	6,000		9,500	12,500	3,000	9,500	7,500
12ProMax	18,000	5,500		7,500	18,000	3,000	7,500	7,500
12/12Pro	16,000	5,500		5,500	19,000	3,000	7,500	7,500
12mini	16,000	5,500		5,500	12,500	3,000	7,500	7,500
SE2	4,000	2,500	3,500	4,000	7,500	2,000	4,500	5,500
11ProMax	14,000	5,500		6,500	12,500	2,000	6,500	6,500
11Pro	10,500	5,500		6,500	12,000	2,000	6,500	6,500
11	8,000	4,500		5,500	9,500	2,000	6,500	5,500
XR	6,500	3,000		5,500	8,000	2,000	5,500	6,500
XSMAX	10,500	4,500		5,500	8,000	2,000	5,500	6,500
XS	7,000	4,000		5,500	8,000	2,000	5,500	6,500
X	6,500	2,500		5,000	7,500	2,000	5,500	5,500
8Plus	3,500	2,500	3,500	5,500	10,000	2,000	2,000	5,500
8	3,000	2,000	3,500	5,500	7,500	2,000	2,000	5,500
7Plus	3,000	2,000	3,500	4,500	9,500	2,000	2,000	4,500
7	2,500	2,000	3,500	4,500	3,000	2,000	2,000	4,500
6sPlus	2,000	2,000	2,000	3,000	2,500	2,000	2,000	3,500
6s	2,000	2,000	2,000	2,500	2,000	2,000	2,000	3,500
6Plus	2,000	2,000	2,000	2,000	2,000	2,000	2,000	2,000
6	2,000	2,000	2,000	2,000	2,000	2,000	2,000	2,000
SE/5 / 5s / 5c	2,000	2,000	2,000	2,000	2,000	2,000	2,000	2,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：無料 復旧が成功しない限り費用はいただきません。							
	成功費：5,500							

消費税込みの表記です。