

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15Plus	49,900	12,900				6,900		
15	47,900	12,900				6,900		
14ProMax	55,900	11,900		18,900	17,000	6,900	12,900	11,900
14Pro	50,900	11,900		18,900	17,000	6,900	12,900	11,900
14Plus	26,900	11,900		15,900	16,000	6,900	12,900	11,900
14	25,900	11,900		13,900	16,000	6,900	12,900	11,900
SE3	5,900	3,900	8,900	9,000	10,000	3,000	7,900	6,500
13ProMax	42,900	10,900		15,900	21,900	4,900	10,900	9,900
13Pro	37,900	10,900		15,900	21,900	4,900	10,900	9,900
13	20,900	7,900		21,000	23,000	7,000	10,900	9,900
13mini	20,900	7,900		19,000	22,000	7,000	10,900	9,900
12ProMax	17,900	7,900		13,900	21,900	4,900	9,900	9,900
12Pro / 12	14,900	6,900		13,900	21,900	4,900	9,900	9,900
12mini	15,900	6,900		13,900	21,900	4,900	9,900	9,900
SE2	4,900	3,900	8,900	5,900	14,900	4,900	7,900	8,900
11ProMax	11,900	6,900		11,900	20,900	4,900	9,900	8,900
11Pro	9,900	6,900		11,900	20,900	4,900	9,900	8,900
11	7,900	5,900		11,900	18,900	4,900	9,900	8,900
XR	6,900	4,900		9,900	12,900	4,900	8,900	5,900
XSMAX	7,900	5,900		9,900	16,900	3,900	9,900	5,900
XS	5,900	4,900		9,900	15,900	3,900	9,900	5,900
X	5,900	4,900		8,900	13,900	3,900	7,900	5,900
8Plus	5,700	4,900	8,900	5,900	13,900	3,900	7,900	4,900
8	5,700	4,900	8,900	5,900	10,900	3,900	5,900	4,900
7Plus	3,900	3,900	8,900	4,900	12,900	3,900	5,900	4,900
7	3,900	3,900	8,900	4,900	8,900	3,900	5,900	4,900
6sPlus	2,900	2,900	4,900	4,900	6,900	3,900	4,900	4,900
6s	2,900	2,900	4,900	4,900	6,900	3,900	4,900	4,900
6Plus	2,900	2,900	3,900	4,900	6,900	3,900	3,900	3,900
6	2,900	2,900	3,900	4,900	4,900	3,900	3,900	3,900
SE	2,900	2,900	3,900	4,900	4,900	3,900	3,900	3,900
5 / 5s / 5c	2,900	2,900	3,900	4,900	4,900	3,900	3,900	3,900
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：2,000 成功費：7,000							

消費税込みの表記です。