

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
14ProMax	29,900	10,900		19,900	20,900	7,900	12,900	10,900
14Pro	28,900	10,900		12,900	20,900	7,900	12,900	10,900
14Plus	14,900	9,900		13,900	18,900	7,900	12,900	10,900
14	13,900	9,900		13,900	18,900	7,900	12,900	10,900
SE3	7,800	2,900	8,900	10,900	11,900	5,900	9,900	10,900
13ProMax	22,900	7,900		16,900	20,900	7,900	11,900	9,900
13Pro	21,900	7,900		16,900	20,900	7,900	11,900	9,900
13	11,900	6,900		10,900	16,900	7,900	11,900	9,900
13mini	13,900	6,900		11,900	16,900	7,900	11,900	9,900
12ProMax	13,900	5,900		11,900	26,900	6,900	10,900	11,900
12Pro / 12	11,900	4,900		9,900	28,900	6,900	10,900	9,900
12mini	12,900	4,900		11,900	16,900	6,900	10,900	11,900
SE2	6,700	2,500	8,900	8,900	11,900	5,900	8,900	7,900
11ProMax	10,900	3,900		12,900	17,900	5,900	9,900	8,900
11Pro	9,900	3,900		12,900	16,900	5,900	9,900	7,900
11	9,900	3,900		10,900	12,900	5,900	9,900	7,900
XR	8,900	2,900		7,900	14,900	6,900	8,900	7,900
XSMAX	10,900	2,900		9,900	14,900	6,900	8,900	7,900
XS	7,900	2,900		9,900	14,900	6,900	8,900	7,900
X	7,900	2,900		9,900	14,900	6,900	8,900	7,900
8Plus	6,500	1,900	8,900	7,900	16,900	4,900	8,900	6,900
8	6,500	1,900	8,900	7,900	10,900	4,900	6,900	6,900
7Plus	5,900	1,900	8,900	6,900	11,900	4,900	5,900	6,900
7	4,900	1,900	8,900	6,900	7,900	4,900	5,900	6,900
6sPlus	3,900	1,800	5,900	5,900	6,900	4,900	5,900	5,900
6s	3,900	1,800	5,900	5,900	6,900	4,900	5,900	5,900
6Plus	3,500	1,800	5,900	5,900	5,900	4,900	5,900	5,900
6	3,500	1,800	5,900	5,900	5,900	4,900	5,900	5,900
SE	3,500	1,800	5,900	5,900	5,900		5,900	5,900
5 / 5s / 5c	3,500	1,800	5,900	5,900	5,900		5,900	5,900
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
修理作業費					2,000			
水没復旧					受付費：2,900			
修理作業費込の金額です。					成功費：6,900			

消費税込みの表記です。