

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15ProMax	44,000			ASK				
15Pro	41,000			ASK				
15Plus	36,000			ASK				
15	36,000			ASK				
14ProMax	38,000	9,900		ASK				
14Pro	36,000	9,900		ASK				
14Plus	22,000	9,900		ASK				
14	21,000	9,900		ASK				
13ProMax	25,500	9,000		ASK				
13Pro	20,500	8,000		ASK				
13mini / 13	14,000	7,000		ASK		7,800		
SE3	7,000	2,400		ASK		3,300		
12ProMax	14,500	5,500		ASK	25,000	5,800	25,000	12,000
12Pro / 12	11,500	4,500		ASK	22,000	5,800	22,000	9,000
12mini	11,500	4,500		ASK	22,000	5,800	22,000	9,000
SE2	4,000	1,400	5,000	ASK	12,000	2,300	8,000	3,000
11ProMax	9,500	4,500		ASK	17,000	4,300	12,000	8,000
11Pro	8,000	3,500		ASK	16,000	4,300	10,000	8,000
11	6,500	1,900		ASK	12,000	4,300	9,000	8,000
XR	6,000	1,500		ASK	10,000	3,300	7,500	7,000
XSMMax	8,500	1,900		ASK	10,000	3,300	7,500	7,000
XS	6,000	1,500		ASK	10,000	3,300	7,500	7,000
X	6,000	1,500		ASK	10,000	3,300	7,500	7,000
8Plus	3,000	900	5,000	ASK	10,000	2,300	7,000	3,000
8	3,000	900	5,000	ASK	10,000	2,300	7,000	3,000
7Plus	3,000	900	5,000	ASK	9,000	2,300	5,500	2,000
7	3,000	900	5,000	ASK	7,000	2,300	5,500	2,000
6sPlus	3,000	900	4,000	ASK	6,000	1,800	4,000	1,000
6s	3,000	900	4,000	ASK	6,000	1,800	4,000	1,000
6Plus / 6	3,000	900	3,000	ASK	6,000	1,800	3,000	1,000
SE / 5 / 5s	3,000	900	3,000	ASK	6,000	1,800	3,000	1,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
修理作業費 1台ごとに必要です。	3,000							
水没復旧 修理作業費込の金額です。				受付費：4,000				
				成功費：5,000				

消費税込みの表記です。