

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
14ProMax	37,500	10,500		12,900	18,900	6,900	10,900	9,900
14Pro	35,500	10,500		12,900	18,900	6,900	10,900	9,900
14Plus	22,500	9,500		11,900	16,900	6,900	10,900	9,900
14	20,500	9,500		11,900	16,900	6,900	10,900	9,900
SE3	5,500	2,900	6,900	8,900	9,900	3,900	7,900	6,900
13ProMax	32,500	7,500		11,900	18,900	5,900	9,900	9,900
13Pro	27,500	7,500		11,900	18,900	5,900	9,900	9,900
13	17,500	6,500		8,900	14,900	5,900	9,900	8,900
13mini	17,500	6,500		9,900	14,900	5,900	9,900	8,900
12ProMax	16,500	6,500		9,900	24,900	4,900	8,900	8,900
12Pro / 12	14,500	5,500		7,900	26,900	4,900	8,900	8,900
12mini	14,500	6,500		9,900	14,900	4,900	8,900	8,900
SE2	5,500	2,500	5,900	6,900	9,900	3,900	6,900	6,900
11ProMax	12,500	5,500		9,900	13,900	4,900	5,900	4,900
11Pro	12,500	5,500		9,900	13,900	4,900	5,900	4,900
11	11,500	4,500		7,900	10,900	4,900	5,900	4,900
XR	10,500	3,500		5,900	7,900	4,900	5,900	4,900
XSMAX	11,500	3,500		5,900	7,900	4,900	5,900	4,900
XS	9,500	3,500		5,900	7,900	4,900	5,900	4,900
X	9,500	3,500		5,900	7,900	4,900	4,500	4,900
8Plus	5,500	2,500	5,900	4,900	7,900	3,900	3,900	2,900
8	5,500	2,500	5,900	4,900	7,900	3,900	3,900	2,900
7Plus	5,500	2,500	4,900	4,900	7,900	3,900	3,900	2,900
7	5,500	2,500	4,900	4,900	8,500	3,900	3,900	2,900
6sPlus	4,500	2,500	3,900	3,900	6,500	3,900	4,500	2,900
6s	4,500	2,500	3,900	3,900	6,500	3,900	2,900	2,900
6Plus	4,500	2,500	2,900	3,900	6,500	2,900	2,900	2,900
6	4,500	2,500	2,900	3,900	4,500	2,900	2,900	2,900
SE	4,500	2,500	2,900	3,900	6,500	2,900	2,900	2,900
5 / 5s / 5c	4,500	2,500	2,900	3,900	4,500	2,900	2,900	2,900
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
<b>修理作業費</b> 1台ごとに必要です。	2,000							
<b>水没復旧</b> 修理作業費込の金額です。	受付費：4,000							
	成功費：5,000							
<b>データ復旧</b> 修理作業費込の金額です。	受付費：5,500							
	成功費：26,400							

消費税込みの表記です。