

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15ProMax	43,000	11,500		ASK				
15Pro	40,000	10,500		ASK				
15Plus	35,000	9,500		ASK				
15	35,000	9,500		ASK				
14ProMax	36,000	9,900		ASK				
14Pro	34,000	9,500		ASK				
14Plus	20,500	7,900		ASK				
14	19,500	7,900		ASK				
13ProMax	24,500	7,900		ASK				
13Pro	19,500	6,900		ASK				
13mini / 13	13,000	5,900		ASK		7,800		
SE3	5,800	1,900		ASK		3,300		
12ProMax	12,900	3,900		ASK	25,000	5,800	25,000	12,000
12Pro / 12	10,900	3,900		ASK	22,000	5,800	22,000	9,000
12mini	10,900	3,900		ASK	22,000	5,800	22,000	9,000
SE2	2,500	700	5,000	ASK	12,000	2,300	8,000	3,000
11ProMax	8,900	3,900		ASK	17,000	4,300	12,000	8,000
11Pro	7,900	2,900		ASK	16,000	4,300	10,000	8,000
11	6,400	1,700		ASK	12,000	4,300	9,000	8,000
XR	5,900	1,400		ASK	10,000	3,300	7,500	7,000
XSMMax	8,400	1,700		ASK	10,000	3,300	7,500	7,000
XS	5,900	1,400		ASK	10,000	3,300	7,500	7,000
X	5,900	1,400		ASK	10,000	3,300	7,500	7,000
8Plus	3,000	400	5,000	ASK	10,000	2,300	7,000	3,000
8	2,500	400	5,000	ASK	10,000	2,300	7,000	3,000
7Plus	3,000	400	5,000	ASK	9,000	2,300	5,500	2,000
7	2,500	400	5,000	ASK	7,000	2,300	5,500	2,000
6sPlus	3,000	400	4,000	ASK	6,000	1,800	4,000	1,000
6s	2,500	400	4,000	ASK	6,000	1,800	4,000	1,000
6Plus / 6	2,500	400	3,000	ASK	6,000	1,800	3,000	1,000
SE / 5 / 5s	2,500	400	3,000	ASK	6,000	1,800	3,000	1,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
修理作業費 1台ごとに必要です。	3,000							
水没復旧 修理作業費込の金額です。				受付費：4,000				
				成功費：5,000				

消費税込みの表記です。