

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15ProMax	32,900	8,900		18,900	25,900	5,900	12,900	10,900
15Pro	30,900	8,900		17,900	25,900	5,900	12,900	10,900
15Plus	31,900	7,900		16,900	18,900	5,900	11,900	10,900
15	29,900	7,900		16,900	17,900	5,900	11,900	10,900
14ProMax	30,500	7,900		12,900	18,900	5,900	10,900	9,900
14Pro	30,500	7,900		12,900	18,900	5,900	10,900	9,900
14Plus	25,900	7,500		11,900	16,900	5,900	10,900	9,900
14	25,900	7,500		11,900	16,900	5,900	10,900	9,900
SE3	6,500	1,900	6,900	8,900	9,900	3,900	7,900	8,900
13ProMax	25,900	6,900		11,900	18,900	5,900	9,900	9,900
13Pro	24,900	6,500		11,900	18,900	5,900	9,900	9,900
13	22,900	6,500		11,900	16,900	6,900	11,900	12,900
13mini	22,900	6,900		12,900	16,900	6,900	11,900	12,900
12ProMax	13,900	5,900		11,900	26,900	6,900	10,900	10,900
12Pro	12,900	4,900		11,900	28,900	6,900	10,900	10,900
12 / 12mini	12,900	4,900		11,900	16,900	6,900	10,900	10,900
SE2	3,900	1,900	9,900	8,900	11,900	4,900	8,900	9,900
11ProMax	10,900	3,900		19,900	21,900	4,900	15,900	9,900
11Pro	9,500	3,900		17,900	19,900	4,900	13,900	9,900
11	7,500	3,900		14,900	17,900	4,900	11,900	9,900
XR	5,900	3,500		8,900	11,900	4,900	8,900	8,900
XSMAX	9,900	3,500		9,900	15,900	4,900	10,900	8,900
XS	7,500	3,500		9,900	14,900	4,900	9,900	8,900
X	7,500	3,500		8,900	12,900	4,900	8,900	7,900
8Plus	3,900	1,900	9,900	5,900	12,900	4,900	7,900	6,900
8	3,900	1,900	9,900	5,900	10,900	4,900	6,900	6,900
7Plus	3,900	1,900	9,900	4,500	11,900	4,900	5,900	6,900
7	3,900	1,900	9,900	4,500	7,900	4,900	5,900	6,900
6sPlus	3,900	1,900	5,500	3,900	5,900	4,900	4,900	4,900
6s	3,900	1,900	5,500	3,900	5,900	4,900	4,900	4,900
6Plus	2,900	1,900	4,500	3,900	6,600	4,900	4,900	4,900
6	2,900	1,900	4,500	3,900	4,900	4,900	4,900	4,900
SE / 5s	2,900	2,900	4,500	3,900	5,900	4,900	4,900	4,900
5 / 5c	4,900	2,900	4,500	3,900	4,900	4,900	4,900	4,900
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：1,900 成功費：6,900							

消費税込みの表記です。