

修理パーツ	パネル			バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
	液晶	A品 / GXOLED	有機EL (純正同等)				アウト	レンズ	イン	
15ProMax	35,860	+ 4,950		19,800						
15Pro	29,810	+ 3,300		17,820						
15Plus	27,830	+ 6,050		12,870						
15	26,840			12,870						
SE3	8,360			5,830						
14ProMax	32,890	+ 3,850		16,830						
14Pro	27,830	+ 3,850		15,400						
14Plus	22,880			11,880						
14	21,780	+ 2,750		11,880						
13ProMax	26,840			12,870						
13Pro	24,860			11,880						
13	12,870	+ 2,970		8,800						
13mini	13,310	+ 3,850		9,350						
12ProMax	13,860			8,800						
12Pro / 12	11,880	+ 2,420	+ 8,800	7,810						
12mini	12,320	+ 2,420		8,360						
SE2	5,830	+ 2,750		4,620		9,900	13,200	6,050	9,900	10,450
11ProMax	9,900	+ 2,200	+ 9,900	6,710		18,480	18,150	6,050	17,050	13,750
11Pro	9,130	+ 1,980	+ 8,800	6,600		16,500	17,050	6,050	15,950	13,200
11	8,800	+ 2,200		6,380		14,850	14,850	6,050	14,850	12,100
XR	8,800	+ 2,200		5,610		11,000	14,300	6,050	11,000	10,450
XSMAX	10,890	+ 2,530	+ 11,000	6,600		12,650	18,150	6,050	13,200	11,550
XS	8,030	+ 1,980	+ 7,150	6,600		12,100	17,600	6,050	12,650	11,000
X	8,030	+ 1,980	+ 7,150	5,610		11,000	15,400	6,050	11,550	10,450
8Plus	6,160	+ 2,530		4,620	8,800	8,800	15,400	4,950	10,450	8,800
8	5,170	+ 2,200		4,620	8,800	8,800	13,200	4,950	9,900	8,800
7Plus	6,160			3,630	7,150	7,150	14,850	4,950	8,250	8,800
7	5,170			3,630	7,150	7,150	10,450	4,950	8,250	8,800
6sPlus	5,170			3,630	6,600	6,600	8,800	4,950	6,600	6,600
6s	4,840			3,630	6,600	6,600	8,800	4,950	6,600	6,600
6Plus	5,390			3,630	6,600	6,600	8,800	4,950	5,500	5,500
6	5,170			3,630	6,600	6,600	6,600	4,950	5,500	5,500
SE /5s	5,060			3,630	6,600	6,600	8,800	4,950	5,500	5,500
5 / 5c	5,060			3,630	6,600	6,600	6,600	4,950	5,500	4,400
修理パーツ	液晶	A品 / GXOLED	有機EL (純正同等)	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
	パネル						カメラ			
修理作業費 1台ごとに必要です。	2,200									
水没復旧 修理作業費込の金額です。	受付費：3,300									
	成功費：7,700									

消費税込みの表記です。