

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			イヤースピーカー	ラウンド スピーカー
					アウト	レンズ	イン		
16e	43,900					7,900			
16Plus	31,900					7,900			
16	30,900					7,900			
15ProMax	23,500	7,900			19,900	7,900	12,900	10,900	10,900
15Pro	20,900	7,900			19,900	7,900	12,900	10,900	10,900
15Plus	19,900	6,900			16,900	7,900	11,900	10,900	10,900
15	16,900	6,900			16,900	7,900	11,900	10,900	10,900
14ProMax	20,900	6,900			19,900	7,900	12,900	9,900	8,900
14Pro	16,900	6,900			18,900	7,900	10,900	9,900	8,900
14Plus	11,900	5,900			16,900	7,900	12,900	9,900	8,900
14	10,900	5,900			17,900	7,900	10,900	9,900	8,900
SE3	2,500	1,900	6,900	9,000	9,900	7,900	7,900	6,900	8,900
13ProMax	15,900	4,900			19,900	4,900	9,900	6,900	6,900
13Pro	15,900	4,900			19,900	4,900	11,900	6,900	6,900
13	9,900	3,900			19,900	4,900	9,900	6,900	6,900
13mini	10,900	3,900			19,900	4,900	11,900	6,900	6,900
12ProMax	11,900	3,900			22,900	4,900	9,900	8,900	6,900
12Pro / 12	6,900	3,900			22,900	4,900	8,900	8,900	6,900
12mini	8,900	3,900			15,900	4,900	8,900	8,900	6,900
SE2	1,900	1,900	6,900	5,900	14,400	3,900	6,900	7,900	5,900
11ProMax	7,900	2,900		8,900	17,900	4,900	7,900	7,900	5,900
11Pro	5,900	1,900		8,900	17,900	4,900	7,900	7,900	5,900
11	5,900	1,900		8,900	12,900	4,900	7,900	7,900	5,900
XR	3,900	1,900		5,900	12,900	4,900	6,900	7,900	5,900
XSMaX	6,900	1,900		7,900	12,900	4,900	6,900	7,900	5,900
XS	4,900	1,900		7,900	12,900	4,900	6,900	7,900	5,900
X	3,900	1,900		7,900	12,900	4,900	6,900	7,900	5,900
8Plus	1,900	1,500	6,900	5,900	14,900	2,900	6,900	4,900	4,900
8	1,900	1,500	6,900	5,900	8,900	2,900	4,900	4,900	4,900
7Plus	1,900	1,500	6,900	4,900	9,900	2,900	3,900	4,900	4,900
7	1,900	1,500	6,900	4,900	5,900	2,900	3,900	4,900	4,900
6sPlus	1,900	1,500	3,900	3,900	4,900	2,900	3,900	3,900	3,900
6s	1,900	1,900	3,900	3,900	4,900	2,900	3,900	3,900	3,900
6Plus	1,900	1,500	3,900	3,900	3,900	2,900	3,900	3,900	3,900
6	1,900	1,500	3,900	3,900	3,900	2,900	3,900	3,900	3,900
SE	1,900	1,500	3,900	3,900	3,900		3,900	3,900	3,900
5 / 5s / 5c	1,900	1,500	3,900	3,900	3,900		3,900	3,900	3,900
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	イヤースピーカー	ラウンド スピーカー
					カメラ				
修理作業費 1台ごとに必要です。2,000									
水没復旧 修理作業費込の金額です。受付費：無料 復旧が成功しない限り費用はいただきません。									
成功費：7000									

消費税込みの表記です。