

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			イヤースピーカー	ラウンド スピーカー	修理パーツ	
					アウト	レンズ	イン				
16e	32,900									16e	
16ProMax	79,900			23,900	22,900	7,900	21,900	13,900	13,900	16ProMax	
16Pro	77,900			22,900	21,900	7,900	16,900	13,900	13,900	16Pro	
16Plus	39,900			22,900	20,900	7,900	16,900	13,900	13,900	16Plus	
16	37,900			21,900	19,900	7,900	15,900	13,900	13,900	16	
15ProMax	31,900	9,500		19,900	21,900	7,900	14,900	12,900	12,900	15ProMax	
15Pro	24,900	9,500		18,900	21,900	7,900	14,900	12,900	12,900	15Pro	
15Plus	20,900	8,900		22,900	18,900	7,900	13,900	12,900	12,900	15Plus	
15	17,900	8,900		18,900	18,900	7,900	13,900	12,900	12,900	15	
14ProMax	25,900	8,900		18,900	21,900	7,900	14,900	11,900	10,900	14ProMax	
14Pro	22,900	8,900		14,900	20,900	7,900	12,900	11,900	10,900	14Pro	
14Plus	18,900	7,900		11,900	18,900	7,900	14,900	11,900	10,900	14Plus	
14	16,900	7,900		11,900	19,900	7,900	12,900	11,900	10,900	14	
SE3	5,500	3,900	8,900	9,900	11,900	5,900	9,900	8,900	10,900	SE3	
13ProMax	20,900	6,900		16,900	21,900	7,900	12,900	11,900	9,900	13ProMax	
13Pro	17,900	6,900		14,900	21,900	7,900	12,900	11,900	9,900	13Pro	
13	13,900	6,500		11,900	16,900	7,900	11,900	10,900	9,900	13	
13mini	12,900	6,500		13,900	16,900	7,900	12,900	10,900	9,900	13mini	
12ProMax	13,500	6,500		11,900	26,900	6,900	10,900	10,900	11,900	12ProMax	
12Pro	11,900	6,500		9,900	27,900	6,900	10,900	10,900	9,900	12Pro	
12	11,900	6,500		9,900	16,900	6,900	10,900	10,900	11,900	12	
12mini	12,500	6,500		9,900	16,900	6,900	10,900	10,900	11,900	12mini	
SE2	4,900	3,900	8,900	8,900	11,900	5,900	8,900	8,900	7,900	SE2	
11ProMax	10,500	4,900		17,900	18,900	5,900	9,900	9,900	8,900	11ProMax	
11Pro	9,500	4,900		16,900	18,900	5,900	9,900	9,900	7,900	11Pro	
11	7,500	4,900		9,900	12,900	5,900	9,900	8,900	7,900	11	
XR	6,500	3,900		8,900	16,900	5,900	7,900	7,900	7,900	XR	
XSMMax	8,500	4,900		9,900	16,900	5,900	7,900	7,900	7,900	XSMMax	
XS	6,500	3,900		9,900	16,900	5,900	7,900	7,900	7,900	XS	
X	6,500	3,900		8,900	15,900	5,900	7,900	7,900	7,900	X	
8Plus	5,500	3,900	8,900	7,900	13,900	4,900	6,900	6,900	6,900	8Plus	
8	4,900	3,900	8,900	8,900	9,900	4,900	6,900	6,900	6,900	8	
7Plus	4,900	3,900	8,900	7,900	13,900	4,900	5,900	6,900	6,900	7Plus	
7	4,900	3,900	8,900	7,900	11,900	4,900	5,900	6,900	6,900	7	
6sPlus	4,500	3,900	5,900	5,900	6,900	4,900	5,900	5,900	5,900	6sPlus	
6s	4,500	3,900	5,900	5,900	6,900	4,900	5,900	5,900	5,900	6s	
6Plus / 6	4,500	3,900	5,900	5,900	5,900	4,900	5,900	5,900	5,900	6Plus / 6	
SE /5 / 5s	4,500	3,900	5,900	5,900	5,900		5,900	5,900	5,900	SE /5 / 5s	
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	イヤースピーカー	ラウンド スピーカー	修理パーツ	
修理作業費 1台ごとに必要です。				2,000						修理作業費 1台ごとに必要です。	
水没復旧 修理作業費込の金額です。				受付費：0 ※成功しなかった場合は費用をいただきません。						水没復旧 修理作業費込の金額です。	
				成功費：9,900							

消費税込みの表記です。