

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			イヤースピーカー	ラウンド スピーカー	修理パーツ
					アウト	レンズ	イン			
16e	31,900									16e
16ProMax	101,900			23,900	22,900	7,900	21,900	13,900	13,900	16ProMax
16Pro	91,900			22,900	21,900	7,900	16,900	13,900	13,900	16Pro
16Plus	39,900			22,900	20,900	7,900	16,900	13,900	13,900	16Plus
16	36,900			21,900	19,900	7,900	15,900	13,900	13,900	16
15ProMax	30,500	6,500		19,900	21,900	7,900	14,900	12,900	12,900	15ProMax
15Pro	23,500	6,500		18,900	21,900	7,900	14,900	12,900	12,900	15Pro
15Plus	18,500	6,500		22,900	18,900	7,900	13,900	12,900	12,900	15Plus
15	15,500	6,500		18,900	18,900	7,900	13,900	12,900	12,900	15
14ProMax	23,500	6,500		18,900	21,900	7,900	14,900	11,900	10,900	14ProMax
14Pro	20,500	6,500		14,900	20,900	7,900	12,900	11,900	10,900	14Pro
14Plus	15,500	6,500		11,900	18,900	7,900	14,900	11,900	10,900	14Plus
14	13,500	6,500		11,900	19,900	7,900	12,900	11,900	10,900	14
SE3	4,900	2,900	8,900	9,900	11,900	5,900	9,900	8,900	10,900	SE3
13ProMax	20,500	5,500		16,900	21,900	7,900	12,900	11,900	9,900	13ProMax
13Pro	14,900	5,500		14,900	21,900	7,900	12,900	11,900	9,900	13Pro
13	10,500	4,500		11,900	16,900	7,900	11,900	10,900	9,900	13
13mini	13,500	5,900		13,900	16,900	7,900	12,900	10,900	9,900	13mini
12ProMax	13,500	4,500		11,900	26,900	6,900	10,900	10,900	11,900	12ProMax
12Pro	10,500	3,900		9,900	27,900	6,900	10,900	10,900	9,900	12Pro
12	10,500	3,900		9,900	16,900	6,900	10,900	10,900	11,900	12
12mini	11,500	4,900		9,900	16,900	6,900	10,900	10,900	11,900	12mini
SE2	3,500	2,900	8,900	8,900	11,900	5,900	8,900	8,900	7,900	SE2
11ProMax	10,500	3,900		17,900	18,900	5,900	9,900	9,900	8,900	11ProMax
11Pro	8,900	3,900		16,900	18,900	5,900	9,900	9,900	7,900	11Pro
11	6,900	2,900		9,900	12,900	5,900	9,900	8,900	7,900	11
XR	6,500	2,900		8,900	16,900	5,900	7,900	7,900	7,900	XR
XSMMax	8,500	2,900		9,900	16,900	5,900	7,900	7,900	7,900	XSMMax
XS	6,500	2,900		9,900	16,900	5,900	7,900	7,900	7,900	XS
X	6,500	2,900		8,900	15,900	5,900	7,900	7,900	7,900	X
8Plus	4,500	2,900	8,900	7,900	13,900	4,900	6,900	6,900	6,900	8Plus
8	4,500	2,900	8,900	8,900	9,900	4,900	6,900	6,900	6,900	8
7Plus	4,500	2,900	8,900	7,900	13,900	4,900	5,900	6,900	6,900	7Plus
7	4,500	2,900	8,900	7,900	11,900	4,900	5,900	6,900	6,900	7
6sPlus	4,500	2,900	5,900	5,900	6,900	4,900	5,900	5,900	5,900	6sPlus
6s	4,500	2,900	5,900	5,900	6,900	4,900	5,900	5,900	5,900	6s
6Plus / 6	4,500	2,900	5,900	5,900	5,900	4,900	5,900	5,900	5,900	6Plus / 6
SE / 5 / 5s	4,500	2,900	5,900	5,900	5,900		5,900	5,900	5,900	SE / 5 / 5s
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	イヤースピーカー	ラウンド スピーカー	修理パーツ
修理作業費 1台ごとに必要です。	2,000									修理作業費 1台ごとに必要です。
水没復旧 修理作業費込の金額です。	受付費：0 ※成功しなかった場合は費用をいただきません。									水没復旧 修理作業費込の金額です。
	成功費：9,900									

消費税込みの表記です。