

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15ProMax	33,900	16,900		22,900	19,900	6,900	14,900	12,900
15Pro	29,900	16,900		22,900	19,900	6,900	14,900	12,900
15Plus	24,900	16,900		22,900	19,900	6,900	14,900	12,900
15	24,900	16,900		22,900	19,900	6,900	14,900	12,900
14ProMax	24,900	11,000		16,900	17,900	6,900	12,900	11,900
14Pro	21,900	11,000		16,900	17,900	6,900	12,900	11,900
14Plus	16,900	13,000		19,900	17,900	6,900	12,900	11,900
14	14,900	13,000		19,900	17,900	6,900	12,900	11,900
13ProMax	21,900	7,900		14,900	19,900	5,900	9,900	9,900
13Pro	19,900	7,900		14,900	19,900	5,900	9,900	9,900
13	11,900	6,900		11,900	16,900	5,900	9,900	9,900
13mini	14,900	6,900		12,900	16,900	5,900	9,900	9,900
SE3	6,900	4,500	4,900	7,700	9,900	3,500	7,900	8,600
12ProMax	14,900	5,900		10,900	17,900	4,900	8,900	8,900
12Pro / 12	11,900	5,900		9,900	17,900	4,900	8,900	8,900
12mini	11,900	5,900		9,900	12,900	4,900	8,900	8,900
SE2	4,900	3,000	4,900	6,900	8,900	3,300	7,000	6,600
11ProMax	9,900	4,500		11,900	15,900	4,500	8,500	6,600
11Pro	8,900	4,500		11,900	14,900	4,500	7,900	6,600
11	8,900	4,500		9,900	9,900	4,500	7,900	6,600
XR	8,500	3,900		7,700	8,900	3,900	7,900	6,600
XSMaх	9,900	3,900		7,700	9,900	3,900	7,900	6,600
XS	7,900	3,900		7,500	9,900	3,900	7,900	6,600
X	7,900	3,900		7,000	8,900	3,900	7,900	6,600
8Plus	5,500	2,900	3,900	6,600	9,900	2,900	5,500	3,900
8	4,900	2,900	3,900	6,400	6,900	2,900	5,500	3,900
7Plus	4,500	2,900	3,900	4,900	7,900	2,900	3,900	3,500
7	3,900	2,900	3,900	4,400	4,900	2,900	3,900	2,900
6sPlus	3,500	2,500	2,500	3,850	4,500	2,900	2,900	2,900
6s	3,000	2,500	2,500	3,850	3,900	2,900	2,900	2,900
6Plus	3,000	2,500	2,500	3,850	3,500	2,900	2,900	2,900
6	3,000	2,500	2,500	3,850	3,500	2,900	2,900	2,900
SE	2,900	2,500	2,500	3,850	3,500	2,900	2,900	2,900
5 / 5s / 5c	2,900	2,500	2,500	3,850	3,500	2,900	2,900	2,500
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：0円(復旧しない場合は費用はかかりません。)							
	成功費：5,500							

消費税込みの表記です。