

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
14ProMax	24,900	10,500		19,900	20,900	7,900	12,900	11,900
14Pro	17,500	10,500		12,900	20,900	7,900	12,900	11,900
14Plus	12,900	10,500		13,900	18,900	7,900	12,900	10,900
14	12,900	10,500		13,900	18,900	7,900	12,900	10,900
SE3	5,500	2,900	8,900	8,900	14,500	5,500	9,900	8,900
13ProMax	15,900	7,500		16,900	20,900	6,900	11,900	9,900
13Pro	15,900	6,500		16,900	20,900	6,900	11,900	9,900
13	11,900	5,500		11,900	16,900	6,900	11,900	9,900
13mini	11,900	5,500		11,900	16,900	6,900	11,900	9,900
12ProMax	10,900	6,500		11,900	26,900	6,900	10,900	11,900
12Pro / 12	8,500	4,900		11,900	28,900	6,900	10,900	9,900
12mini	9,900	4,900		9,900	16,900	6,900	10,900	11,900
SE2	3,500	2,900	8,900	8,900	13,000	3,500	8,900	7,900
11ProMax	9,900	4,900		12,900	17,900	5,500	9,900	7,900
11Pro	6,900	4,900		12,900	16,900	5,500	9,900	7,900
11	5,500	3,900		10,900	12,900	5,500	9,900	7,900
XR	5,500	3,900		7,500	10,900	5,500	7,500	6,900
XSMaX	8,900	3,900		9,000	13,900	5,500	7,900	7,900
XS	4,900	2,900		8,500	13,900	5,500	7,900	7,500
X	6,500	2,900		7,500	13,900	5,500	7,900	6,900
8Plus	3,500	2,900	8,500	5,000	11,900	3,500	6,900	5,500
8	3,500	2,900	8,500	5,000	11,900	3,500	6,900	5,500
7Plus	3,500	2,900	8,500	5,000	9,900	2,500	6,500	5,500
7	3,500	2,900	8,500	4,500	11,500	2,000	4,900	5,500
6sPlus	3,500	2,900	8,500	5,500	6,900	2,000	4,900	5,500
6s	3,500	2,900	4,500	2,500	5,500	2,000	3,500	3,500
6Plus	3,500	2,900	4,500	2,500	5,500	2,000	3,500	3,500
6	3,500	2,900	3,500	2,500	5,500	2,000	2,000	2,000
5 / 5s / 5c	3,500	2,900	3,500	2,500	3,500	2,000	2,000	2,000
SE	3,500	2,900	3,500	2,500	5,500	2,000	2,000	2,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。2,000								
水没復旧 修理作業費込の金額です。受付費：3,900								
成功費：4,900								

消費税込みの表記です。