

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
					アウト	レンズ	イン	
15ProMax	55,000 (事前予約でパーツ発注)					11,000		
15Pro	48,000 (事前予約でパーツ発注)					11,000		
15Plus	46,000 (事前予約でパーツ発注)					11,000		
15	40,000 (事前予約でパーツ発注)					11,000		
14ProMax	52,000 (事前予約でパーツ発注)	20,000		27,000	30,000	9,000	23,000	18,000
14Pro	45,000 (事前予約でパーツ発注)	19,000		25,000	28,000	9,000	22,000	17,000
14Plus	28,000	15,000		23,000	25,000	9,000	21,000	16,000
14	25,000	13,000		22,000	24,000	9,000	20,000	15,000
SE3	8,000	6,000	6,500	9,000	10,000	3,000	6,000	6,500
13ProMax	43,000 (事前予約でパーツ発注)	15,000		25,000	28,000	7,000	19,000	17,000
13Pro	41,000 (事前予約でパーツ発注)	14,000		23,000	26,000	7,000	18,000	16,000
13	19,000	13,000		21,000	23,000	7,000	17,000	14,000
13mini	19,000	13,000		19,000	22,000	7,000	16,000	13,000
12ProMax	16,000	8,000		17,000	17,000	5,000	15,000	12,000
12Pro	14,500	8,000		17,000	17,000	5,000	15,000	12,000
12	14,500	8,000		17,000	17,000	5,000	15,000	12,000
12mini	15,500	8,000		15,000	14,000	5,000	13,000	10,000
SE2	7,000	5,500	5,500	8,000	9,000	3,000	5,500	6,000
11ProMax	13,000	7,500		14,000	13,500	3,000	12,500	9,500
11Pro	12,000	7,500		13,000	12,500	3,000	11,500	9,000
11	11,000	7,500		12,500	10,500	3,000	10,500	8,500
XR	10,000	6,000		7,000	10,000	3,000	8,500	6,500
XSMax	11,000	6,500		8,000	11,500	3,000	10,000	7,000
XS	10,000	6,000		7,500	11,000	3,000	8,500	6,000
X	9,000	6,000		7,500	10,500	3,000	8,000	5,500
8Plus	7,000	5,500	5,000	7,000	11,550	3,000	5,500	4,500
8	6,000	5,000	5,000	7,000	9,000	3,000	5,000	4,500
7Plus	6,500	5,000	4,500	6,500	10,500	3,000	5,000	4,000
7	6,000	5,000	4,500	6,500	8,000	3,000	4,500	4,000
6sPlus	5,500	4,000	4,000	4,500	4,000	3,000	3,000	3,000
6/6Plus/6s	5,000	4,000	3,500	4,500	4,000	3,000	3,000	3,000
5s/SE	4,000	4,000	3,500	4,500	4,500	3,000	2,500	3,000
5 / 5c	4,000	4,000	3,500	4,500	4,000	3,000	2,500	3,000
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
					カメラ			
修理作業費 1台ごとに必要です。	2,000							
水没復旧 修理作業費込の金額です。	受付費：2,000							
	成功費：7,000							