

iPad・iPod修理メニュー ※全て税込・作業費込価格です。 ※赤字のメニューは事前予約により即日修理が可能な場合がありますのでお問い合わせください。											
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	ドックコネクター	インカメラ	アウトカメラ	ホームボタン	ボタンSW	イヤースピーカー	外部スピーカー	機種名
iPad 1st	14,600	21,600	13,600	14,100	12,400	12,400	12,600	13,600		13,600	iPad 1st
iPad 2nd / 3rd	13,600	17,600	13,600	14,100	12,400	12,400	12,600	13,600		13,600	iPad 2nd / 3rd
iPad 4th	14,600	17,600	13,600	14,100	12,400	12,400	12,600	13,600		13,600	iPad 4th
iPad 5th 2017/ 6th 2018	16,100	24,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad 5th 2017/ 6th 2018
iPad 7th 2019/ 8th 2020	16,600	24,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad 7th 2019/ 8th 2020
iPad 9th 2021	17,600	25,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad 9th 2021
iPad 10th 2022	18,600	38,600	14,600	15,600	15,600	15,600		13,600		13,600	iPad 10th 2022
iPad Air	14,600	22,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad Air
iPad Air2	26,600	26,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad Air2
iPad Air3	29,600	29,600	14,600	15,600	14,600	14,600	12,600	18,600		18,600	iPad Air3
iPad Air4	31,400	31,400	15,600	15,100	14,600	14,600		14,600		14,600	iPad Air4
iPad Air5	31,400	31,400	15,600	15,100	14,600	14,600		16,600		16,600	iPad Air5
iPad mini	14,600	18,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad mini
iPad mini2	14,600	20,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad mini2
iPad mini3	15,100	20,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad mini3
iPad mini4/ mini5	25,600	25,600	13,600	14,100	14,100	14,100	12,600	13,600		13,600	iPad mini4/ mini5
iPad mini6	47,600	47,600	15,600	15,100	15,100	15,100		15,600		15,600	iPad mini6
iPad Pro 9.7	28,600	28,600	14,600	15,600	15,600	15,600	12,600	16,600		16,600	iPad Pro 9.7
iPad Pro 10.5	29,600	29,600	16,100	15,600	15,600	15,600	12,600	18,600		18,600	iPad Pro 10.5
iPad Pro 11 1st / 2nd / 3rd / 4th	37,600	37,600	16,100	15,100	15,100	15,100		14,600		14,600	iPad Pro 11 1st / 2nd / 3rd / 4th
iPad Pro 12.9 1st	38,600	38,600	16,100	16,100	16,100	16,100	13,600	16,600		16,600	iPad Pro 12.9 1st
iPad Pro 12.9 2nd	64,600	64,600	16,100	16,100	16,100	16,100	13,600	16,600		16,600	iPad Pro 12.9 2nd
iPad Pro 12.9 3rd / 4th	37,600	37,600	16,100	15,100	15,100	15,100		16,100		16,100	iPad Pro 12.9 3rd / 4th
iPad Pro 12.9 5th / 6th	49,600	49,600	18,600	15,100	15,100	15,100		20,600		20,600	iPad Pro 12.9 5th / 6th
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	ドックコネクター	インカメラ	アウトカメラ	ホームボタン	ボタンSW	イヤホンジャック	外部スピーカー	機種名
※iPod Touch 1st	15,180	15,180	14,080	16,280			16,280	16,280	13,640		※iPod Touch 1st
※iPod Touch 2nd / 3rd	15,180	15,180	14,080	16,280			14,520	16,280	13,640	13,750	※iPod Touch 2nd / 3rd
iPod Touch 4th	13,600	13,600	12,100	12,600	12,100	11,100	12,600	12,600	12,600	13,100	iPod Touch 4th
iPod Touch 5th / 6th / 7th	14,100	14,100	12,100	13,600	12,100	11,100	13,600	13,600	13,600	13,100	iPod Touch 5th / 6th / 7th
機種名/症状	ガラス破損	ガラス+液晶	バッテリー	ドックコネクター	インカメラ	アウトカメラ	ホームボタン	ボタンSW	イヤホンジャック	外部スピーカー	機種名
※iPod mini1	22,880	22,880	27,280	17,380							※iPod mini1
※iPod mini2	17,380	17,380	27,280	12,980							※iPod mini2
※iPod nano 1	20,680	20,680	24,200	11,880				15,400			※iPod nano 1
※iPod nano 2	22,880	22,880	24,200	11,880				13,750			※iPod nano 2
※iPod nano 3	17,380	17,380	17,380	14,080				13,750			※iPod nano 3
※iPod nano 4	16,280	16,280	17,380	14,080				13,750	14,080		※iPod nano 4
※iPod nano 5	16,280	16,280	14,080	14,080		13,750		13,750	14,080	14,520	※iPod nano 5
※iPod nano 6	16,280	16,280	14,080	15,180					15,180		※iPod nano 6
※iPod nano 7/7 Mid	16,280	16,280	15,180	15,180			11,550	13,750	15,180		※iPod nano 7/7 Mid

※「※」印のある機種については、パーツをお取り寄せしてからの修理になる場合がございます。