

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカ	修理パーツ
					アウト	レンズ	イン		
16e	32,300				14,300	3,300	10,300	10,300	16e
16ProMax	54,300	9,900		21,900	16,300	3,300	13,300	10,300	16ProMax
16Pro	54,300	9,900		20,900	16,300	3,300	13,300	10,300	16Pro
16Plus	32,300	9,900		20,900	14,300	3,300	10,300	10,300	16Plus
16	32,300	9,900		19,900	14,300	3,300	10,300	10,300	16
15ProMax	30,300	8,300		18,900	15,300	3,300	11,300	8,300	15ProMax
15Pro	30,300	8,300		17,900	15,300	3,300	11,300	8,300	15Pro
15Plus	31,900	7,900		16,900	18,900	3,300	11,900	10,900	15Plus
15	28,300	8,300		16,900	13,300	3,300	10,300	8,300	15
14ProMax	28,300	7,300		12,900	13,300	3,300	10,300	7,300	14ProMax
14Pro	28,300	7,300		12,900	13,300	3,300	10,300	7,300	14Pro
14Plus	25,300	7,300		12,900	12,300	3,300	10,300	7,300	14Plus
14	25,300	7,300		11,900	12,300	3,300	10,300	7,300	14
SE3	7,500	2,900	4,300	8,900	3,300	3,300	3,300	3,300	SE3
13ProMax	24,300	6,500		11,900	12,300	3,300	9,300	6,300	13ProMax
13Pro	24,300	6,500		11,900	12,300	3,300	9,300	6,300	13Pro
13	22,300	6,500		11,900	10,300	3,300	8,300	6,300	13
13mini	22,300	6,300		12,900	10,300	3,300	8,300	6,300	13mini
12ProMax	16,300	5,300		11,900	12,300	3,300	12,300	6,300	12ProMax
12Pro	16,300	5,300		11,900	12,300	3,300	12,300	6,300	12Pro
12 / 12mini	15,300	5,300		11,900	10,300	3,300	8,300	6,300	12 / 12mini
SE2	5,300	2,900	4,300	8,900	3,300	3,300	3,300	3,300	SE2
11ProMax	12,300	4,500		19,900	8,300	3,300	8,300	5,300	11ProMax
11Pro	12,300	4,500		17,900	8,300	3,300	8,300	5,300	11Pro
11	7,300	4,500		14,900	6,300	3,300	6,300	5,300	11
XR	7,300	4,300		8,900	6,300	3,300	6,300	5,300	XR
XSMaX	9,300	3,500		9,900	5,300	3,300	5,300	4,300	XSMaX
XS	7,500	3,500		9,900	4,300	3,300	4,300	4,300	XS
X	7,300	3,500		8,900	4,300	3,300	4,300	4,300	X
8Plus	3,900	1,900	4,300	5,900	12,900	3,300	7,900	5,900	8Plus
8	3,900	1,900	4,300	5,900	10,900	3,300	6,900	6,900	8
7Plus	3,900	1,900	4,300	4,500	11,900	3,300	7,900	4,500	7Plus
7	3,900	1,900	4,300	4,500	7,900	3,300	5,900	4,500	7
6sPlus	3,500	1,900	4,300	3,900	5,900	3,300	4,900	3,900	6sPlus
6s	3,500	1,900	4,300	3,900	5,900	3,300	4,900	3,900	6s
6Plus	2,900	1,900	4,300	3,900	6,600	3,300	4,900	3,900	6Plus
6	2,900	1,900	4,300	3,900	4,900	3,300	4,900	3,900	6
SE / 5s	2,900	2,900	4,300	3,900	5,900	3,300	4,900	3,900	SE / 5s
5 / 5c	3,900	2,900	4,300	3,900	4,900	3,300	4,900	3,900	5 / 5c
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカ	修理パーツ
					カメラ				
修理作業費 1台ごとに必要です。2,000									
修理作業費 1台ごとに必要です。									
水没復旧 修理作業費込の金額です。受付費：1,900									
水没復旧 修理作業費込の金額です。成功費：6,900									

消費税込みの表記です。