

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー	修理パーツ			
					アウト	レンズ	イン					
16e	32,300				14,300	3,300	10,300	10,300	16e			
16ProMax	54,300	9,900		21,900	16,300	3,300	13,300	10,300	16ProMax			
16Pro	54,300	9,900		20,900	16,300	3,300	13,300	10,300	16Pro			
16Plus	32,300	9,900		20,900	14,300	3,300	10,300	10,300	16Plus			
16	32,300	9,900		19,900	14,300	3,300	10,300	10,300	16			
15ProMax	30,300	8,300		18,900	15,300	3,300	11,300	8,300	15ProMax			
15Pro	30,300	8,300		17,900	15,300	3,300	11,300	8,300	15Pro			
15Plus	31,900	7,900		16,900	18,900	3,300	11,900	10,900	15Plus			
15	28,300	8,300		16,900	13,300	3,300	10,300	8,300	15			
14ProMax	28,300	7,300		12,900	13,300	3,300	10,300	7,300	14ProMax			
14Pro	28,300	7,300		12,900	13,300	3,300	10,300	7,300	14Pro			
14Plus	25,300	7,300		12,900	12,300	3,300	10,300	7,300	14Plus			
14	25,300	7,300		11,900	12,300	3,300	10,300	7,300	14			
SE3	7,500	2,900	4,300	8,900	3,300	3,300	3,300	3,300	SE3			
13ProMax	24,300	6,500		11,900	12,300	3,300	9,300	6,300	13ProMax			
13Pro	24,300	6,500		11,900	12,300	3,300	9,300	6,300	13Pro			
13	22,300	6,500		11,900	10,300	3,300	8,300	6,300	13			
13mini	22,300	6,300		12,900	10,300	3,300	8,300	6,300	13mini			
12ProMax	16,300	5,300		11,900	12,300	3,300	12,300	6,300	12ProMax			
12Pro	16,300	5,300		11,900	12,300	3,300	12,300	6,300	12Pro			
12 / 12mini	15,300	5,300		11,900	10,300	3,300	8,300	6,300	12 / 12mini			
SE2	5,300	2,900	4,300	8,900	3,300	3,300	3,300	3,300	SE2			
11ProMax	12,300	4,500		19,900	8,300	3,300	8,300	5,300	11ProMax			
11Pro	12,300	4,500		17,900	8,300	3,300	8,300	5,300	11Pro			
11	7,300	4,500		14,900	6,300	3,300	6,300	5,300	11			
XR	7,300	4,300		8,900	6,300	3,300	6,300	5,300	XR			
XSMAX	9,300	3,500		9,900	5,300	3,300	5,300	4,300	XSMAX			
XS	7,500	3,500		9,900	4,300	3,300	4,300	4,300	XS			
X	7,300	3,500		8,900	4,300	3,300	4,300	4,300	X			
8Plus	3,900	1,900	9,900	5,900	12,900	4,900	7,900	5,900	8Plus			
8	3,900	1,900	9,900	5,900	10,900	4,900	6,900	6,900	8			
7Plus	3,900	1,900	9,900	4,500	11,900	4,900	7,900	4,500	7Plus			
7	3,900	1,900	9,900	4,500	7,900	4,900	5,900	4,500	7			
6sPlus	3,500	1,900	5,500	3,900	5,900	4,900	4,900	3,900	6sPlus			
6s	3,500	1,900	5,500	3,900	5,900	4,900	4,900	3,900	6s			
6Plus	2,900	1,900	4,500	3,900	6,600	4,900	4,900	3,900	6Plus			
6	2,900	1,900	4,500	3,900	4,900	4,900	4,900	3,900	6			
SE / 5s	2,900	2,900	4,500	3,900	5,900	4,900	4,900	3,900	SE / 5s			
5 / 5c	3,900	2,900	4,500	3,900	4,900	4,900	4,900	3,900	5 / 5c			
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー	修理パーツ			
					カメラ							
修理作業費 1台ごとに必要です。	2,000								修理作業費 1台ごとに必要です。			
水没復旧 修理作業費込の金額で す。	受付費：1,900								水没復旧 修理作業費込の金額で す。			
	成功費：6,900											

消費税込みの表記です。