

修理パーツ	液晶パネル	有機ELパネル (OLED)	バッテリー	フロントセンサー ・ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー (イヤスピーカー ・ラウドスピーカー)
						アウト	レンズ	イン	
17e	26,500	30,500		8,000	20,000	19,000	5,000	16,500	11,500
17ProMax	40,000	45,000		8,000	22,000	22,000	5,000	18,000	12,500
17Pro	36,000	41,000		8,000	21,500	21,500	5,000	17,500	12,000
17Air				8,000	21,000	21,000	5,000	17,000	11,500
17	31,000	36,000		8,000	20,000	20,500	5,000	16,000	11,000
16e	19,500	24,500		7,500	18,000	18,000	4,000	15,500	10,000
16ProMax	34,000	38,000	8,000	7,500	20,000	20,000	4,000	15,000	11,500
16Pro	31,000	36,000	8,000	7,500	19,500	19,000	4,000	14,500	11,000
16Plus	23,000	28,000	8,000	7,500	19,000	18,500	4,000	14,000	10,500
16	20,000	25,000	8,000	7,500	18,000	17,500	4,000	13,500	10,000
15ProMax	25,500	30,000	7,000	7,000	16,000	18,000	3,000	12,500	10,000
15Pro	24,000	29,000	7,000	7,000	15,500	16,500	3,000	12,000	9,500
15Plus	19,000	24,000	7,000	7,000	15,500	16,000	3,000	11,500	9,000
15	15,000	22,000	7,000	7,000	14,500	15,500	3,000	11,000	9,000
14ProMax	19,000	24,000	6,000	6,500	12,500	15,000	3,000	10,500	8,000
14Pro	17,000	22,000	5,000	6,500	12,000	15,000	3,000	10,500	8,000
14Plus	11,500	18,000	4,500	6,500	12,000	14,000	3,000	11,000	8,000
14	10,500	17,000	4,500	6,500	10,000	14,000	3,000	11,000	8,000
SE3	3,000		2,500	5,500	6,500	7,500	2,500	5,500	5,500
13ProMax	16,000	21,000	4,500	6,000	10,500	14,000	3,000	9,000	7,500
13Pro	14,500	19,000	4,500	6,000	9,500	14,000	3,000	9,000	7,500
13	9,000	15,000	4,500	6,000	9,000	12,500	3,000	9,000	7,500
13mini	11,000	23,000	4,500	6,000	9,000	12,500	3,000	9,000	7,500
12ProMax	9,500	15,000	4,000		7,500	18,000	3,000	7,500	7,500
12Pro	8,500	13,500	3,000		5,500	19,000	3,000	7,500	7,500
12	8,500	13,500	3,000		5,500	12,500	3,000	7,500	7,500
12mini	9,500	16,500	3,000		5,500	12,500	3,000	7,500	7,500
SE2	3,000		2,000	3,500	4,000	7,500	2,000	4,500	4,500
11ProMax	7,000	13,000	3,500		5,500	12,500	2,000	6,500	6,500
11Pro	5,500	11,000	3,000		5,500	12,000	2,000	6,500	6,500
11	5,000		2,500		5,500	9,500	2,000	6,500	5,500
XR	4,000		2,000		5,500	8,000	2,000	5,500	5,500
XSMAX	5,500	11,000	2,500		5,500	8,000	2,000	5,500	5,500
XS	4,000	8,000	2,500		5,500	8,000	2,000	5,500	5,500
X	3,500	8,000	2,000		5,000	7,500	2,000	5,500	5,500
8Plus	3,000		2,000	3,500	5,500	10,000	2,000	2,000	4,500
8	2,500		2,000	3,500	5,500	7,500	2,000	2,000	4,500
7Plus	2,500		2,000	3,500	4,500	9,500	2,000	2,000	4,500
7	2,000		2,000	3,500	4,500	3,000	2,000	2,000	4,500
6s/6sPlus	2,000		2,000	2,000	2,000	2,000	2,000	2,000	2,000
6/6Plus	2,000		2,000	2,000	2,000	2,000	2,000	2,000	2,000
SE/5/5s/5c	2,000		2,000	2,000	2,000	2,000	2,000	2,000	2,000
修理パーツ	液晶パネル	有機ELパネル (OLED)	バッテリー	フロントセンサー ・ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー (イヤスピーカー ・ラウドスピーカー)
修理作業費 1台ごとに必要です。	2,000								
水没復旧 修理作業費込の金額です。	受付費：無料 復旧が成功しない限り費用はいただきません。								
	成功費：5,500								

消費税込みの表記です。