

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			イヤースピーカー	ラウンド スピーカー	修理パーツ
					アウト	レンズ	イン			
17e	16,900									17e
17ProMax	42,900									17ProMax
17Pro	40,900									17Pro
17	35,900	10,900								17
Air	調整中									Air
16e	16,900									16e
16ProMax	27,900	7,500		21,900	20,900	5,900	19,900	11,900	11,900	15ProMax
16Pro	25,900	7,000		20,900	19,900	5,900	14,900	11,900	11,900	15Pro
16Plus	19,900	7,000		20,900	18,900	5,900	14,900	11,900	11,900	16Plus
16	17,500	7,000		19,900	17,900	5,900	13,900	11,900	11,900	16
15ProMax	17,900	6,800		17,900	19,900	5,900	12,900	10,900	10,900	15ProMax
15Pro	15,400	6,300		16,900	19,900	5,900	12,900	10,900	10,900	15Pro
15Plus	13,900	6,300		20,900	16,900	5,900	11,900	10,900	10,900	15Plus
15	10,900	6,300		16,900	16,900	5,900	11,900	10,900	10,900	15
14ProMax	16,700	5,800		16,900	19,900	5,900	12,900	9,900	8,900	14ProMax
14Pro	13,900	5,300		12,900	18,900	5,900	10,900	9,900	8,900	14Pro
14Plus	10,900	5,300		9,900	16,900	5,900	12,900	9,900	8,900	14Plus
14	8,900	5,300		9,900	17,900	5,900	10,900	9,900	8,900	14
SE3	2,500	1,500	6,900	9,000	9,900	5,900	7,900	6,900	8,900	SE3
13ProMax	13,900	4,300		14,900	19,900	4,900	9,900	6,900	6,900	13ProMax
13Pro	12,900	3,800		12,900	19,900	4,900	11,900	6,900	6,900	13Pro
13	8,500	3,800		9,900	19,900	4,900	9,900	6,900	6,900	13
13mini	8,900	3,800		11,900	19,900	4,900	11,900	6,900	6,900	13mini
12ProMax	8,900	3,500		9,900	22,900	4,900	9,900	8,900	6,900	12ProMax
12Pro / 12	5,900	3,500		7,900	22,900	4,900	8,900	8,900	6,900	12Pro / 12
12mini	7,900	3,500		7,900	15,900	4,900	8,900	8,900	6,900	12mini
SE2	1,900	1,500	6,900	5,900	14,400	3,900	6,900	7,900	5,900	SE2
11ProMax	7,500	3,500		8,900	17,900	4,900	7,900	7,900	5,900	11ProMax
11Pro	4,900	1,500		8,900	17,900	4,900	7,900	7,900	5,900	11Pro
11	4,500	1,500		8,900	12,900	4,900	7,900	7,900	5,900	11
XR	3,900	1,500		5,900	12,900	4,900	6,900	7,900	5,900	XR
XSMaх	6,500	1,900		7,900	12,900	4,900	6,900	7,900	5,900	XSMaх
XS	4,900	1,900		7,900	12,900	4,900	6,900	7,900	5,900	XS
X	3,900	1,500		7,900	12,900	4,900	6,900	7,900	5,900	X
8Plus	1,900	1,500	6,900	5,900	14,900	2,900	6,900	4,900	4,900	8Plus
8	1,900	1,500	6,900	5,900	8,900	2,900	4,900	4,900	4,900	8
7Plus	1,900	1,500	6,900	4,900	9,900	2,900	3,900	4,900	4,900	7Plus
7	1,900	1,500	6,900	4,900	5,900	2,900	3,900	4,900	4,900	7
6sPlus	1,900	1,500	3,900	3,900	4,900	2,900	3,900	3,900	3,900	6sPlus
6s	1,900	1,500	3,900	3,900	4,900	2,900	3,900	3,900	3,900	6s
6Plus	1,900	1,500	3,900	3,900	3,900	2,900	3,900	3,900	3,900	6Plus
6	1,900	1,500	3,900	3,900	3,900	2,900	3,900	3,900	3,900	6
SE	1,900	1,500	3,900	3,900	3,900		3,900	3,900	3,900	SE
5 / 5s / 5c	1,900	1,500	3,900	3,900	3,900		3,900	3,900	3,900	5 / 5s / 5c
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	イヤースピーカー	ラウンド スピーカー	修理パーツ
修理作業費 1台ごとに必要です。	2,000									修理作業費 1台ごとに必要です。
水没復旧 修理作業費込の金額です	受付費：無料 復旧が成功しない限り費用はいただきません。									水没復旧 修理作業費込の金額です
	成功費：7000									

消費税込みの表記です。