

修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー	修理パーツ
					アウト	レンズ	イン		
16e	18,000	7,500		ASK					16e
16ProMax	29,000	7,500		ASK					16ProMax
16Pro	25,000	7,500		ASK					16Pro
16Plus	22,000	7,500		ASK					16Plus
16	20,000	7,500		ASK					16
15ProMax	23,000	5,500		ASK					15ProMax
15Pro	22,000	5,500		ASK					15Pro
15Plus	14,000	5,500		ASK					15Plus
15	13,000	5,500		ASK					15
14ProMax	22,000	4,500		ASK					14ProMax
14Pro	20,000	4,500		ASK					14Pro
14Plus	12,000	4,500		ASK					14Plus
14	11,000	4,500		ASK					14
13ProMax	13,000	3,500		ASK					13ProMax
13Pro	11,000	3,500		ASK					13Pro
13mini / 13	9,000	3,500		ASK		7,800			13mini / 13
SE3	2,500	1,400		ASK		3,300			SE3
12ProMax	7,500	2,500		ASK	25,000	5,800	25,000	12,000	12ProMax
12Pro / 12	6,500	2,500		ASK	22,000	5,800	22,000	9,000	12Pro / 12
12mini	7,500	2,500		ASK	22,000	5,800	22,000	9,000	12mini
SE2	2,500	500	5,000	ASK	12,000	2,300	8,000	3,000	SE2
11ProMax	7,000	2,500		ASK	17,000	4,300	12,000	8,000	11ProMax
11Pro	5,500	1,500		ASK	16,000	4,300	10,000	8,000	11Pro
11	4,500	1,500		ASK	12,000	4,300	9,000	8,000	11
XR	4,500	1,400		ASK	10,000	3,300	7,500	7,000	XR
XSMax	5,000	1,500		ASK	10,000	3,300	7,500	7,000	XSMax
XS	4,500	1,400		ASK	10,000	3,300	7,500	7,000	XS
X	4,500	1,400		ASK	10,000	3,300	7,500	7,000	X
8Plus	3,000	400	5,000	ASK	10,000	2,300	7,000	3,000	8Plus
8	2,500	400	5,000	ASK	10,000	2,300	7,000	3,000	8
7Plus	3,000	400	5,000	ASK	9,000	2,300	5,500	2,000	7Plus
7	2,500	400	5,000	ASK	7,000	2,300	5,500	2,000	7
6sPlus	3,000	400	4,000	ASK	6,000	1,800	4,000	1,000	6sPlus
6s	2,500	400	4,000	ASK	6,000	1,800	4,000	1,000	6s
6Plus / 6	2,500	400	3,000	ASK	6,000	1,800	3,000	1,000	6Plus / 6
SE / 5 / 5s	2,500	400	3,000	ASK	6,000	1,800	3,000	1,000	SE / 5 / 5s
修理パーツ	液晶パネル	バッテリー	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー	修理パーツ
修理作業費 1台ごとに必要です。	3,000							修理作業費 1台ごとに必要です。	
水没復旧 修理作業費込の金額です。	受付費：4,000 成功費：5,000							水没復旧 修理作業費込の金額です。	

消費税込みの表記です。