

修理パーツ	液晶パネル	バッテリー	背面	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
						アウト	レンズ	イン	
17e	お問い合わせください	お問い合わせください							
17ProMax	35,000				お問い合わせください				
17Pro	33,000								
17	28,000								
16e	14,000		18,000						
16ProMax	28,000		20,000						
16Pro	25,000		18,000						
16Plus	21,000			18,000					
16	19,000	13,000	18,000						
15ProMax	21,000	10,000	18,000		25,000	19,900	7,000	12,900	10,900
15Pro	19,000	10,000	16,500		25,000	19,900	7,000	12,900	10,900
15Plus	17,000	10,000	16,000		22,000	16,900	7,000	11,900	10,900
15	16,000	10,000	16,000		22,000	16,900	7,000	11,900	10,900
14ProMax	20,000	8,000	22,000		20,000	19,900	7,000	18,000	9,000
14Pro	18,000	8,000	19,500		20,000	18,900	7,000	18,000	9,000
14Plus	15,000	8,000	16,000		17,000	16,900	7,000	16,000	9,000
14	13,000	8,000	16,000		17,000	17,900	7,000	15,000	7,000
SE3	8,000	4,000		6,000	10,000	9,900	3,900	7,000	7,000
SE2	5,000	3,000		6,000	10,000	9,900	3,900	7,000	6,900
13ProMax	15,000	7,000	19,000		12,500	19,900	7,000	20,000	9,000
13Pro	15,000	7,000	19,000		12,500	19,900	7,000	20,000	9,000
13	12,000	7,000	13,000		11,000	14,900	7,000	13,000	9,000
13mini	12,000	7,000	13,000		11,000	14,900	7,000	13,000	9,000
12ProMax	12,000	5,500	13,000		10,000	24,900	6,000	14,000	9,000
12Pro	10,000	5,500	13,000		10,000	25,900	6,000	12,000	9,000
12	9,000	5,500	13,000		10,000	25,900	6,000	12,000	9,000
12mini	10,000	5,500	13,000		10,000	14,900	6,000	12,000	9,000
11ProMax	8,000	5,000	13,000		13,500	16,900	5,000	14,000	9,000
11Pro	7,000	5,000	13,000		13,500	16,900	5,000	13,000	9,000
11	7,000	5,000	13,000		12,000	10,900	5,000	13,000	9,000
修理パーツ	液晶パネル	バッテリー	背面	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
						カメラ			
修理作業費 1台ごとに必要です。	2,000								
水没復旧 修理作業費込の金額です。	受付費：4,000								
	成功費：5,000								

消費税込みの表記です。

修理パーツ	液晶パネル	バッテリー	背面	ホームボタン	充電 マイク 各種ボタン	カメラ			スピーカー
						アウト	レンズ	イン	
XR	6,500	4,000	9,000		10,000	9,000	3,900	10,000	9,000
XSMaх	8,000	4,000	9,000		10,000	9,000	3,900	10,000	9,000
XS	7,500	4,000	9,000		10,000	9,000	3,900	10,000	8,000
X	6,500	4,000	9,000		10,000	9,000	3,900	10,000	8,000
8Plus	5,000	3,000	9,000	5,000	10,000	9,000	2,900	7,000	6,000
8	5,000	3,000	9,000	5,000	10,000	9,000	2,900	7,000	6,000
7Plus	5,000	3,000		5,000	9,000	7,000	2,900	7,000	6,000
7	5,000	3,000		5,000	9,000	7,000	2,900	7,000	6,000
6sPlus	3,000	2,500		3,900		4,900	2,900	3,900	3,900
6s	3,000	2,500		3,900		4,900	2,900	3,900	3,900
6Plus	3,000	2,500		3,900		4,900	2,900	3,900	3,900
6	3,000	2,500		3,900		4,900	2,900	3,900	3,900
SE	3,000	2,500		3,900		4,900	2,900	3,900	3,900
5 / 5s / 5c	3,000	2,500		3,900		4,900	2,900	3,900	3,900
修理パーツ	液晶パネル	バッテリー	背面	ホームボタン	充電 マイク 各種ボタン	アウト	レンズ	イン	スピーカー
						カメラ			
修理作業費 1台ごとに必要です。	2,000								
水没復旧 修理作業費込の金額です。	受付費：4,000								
	成功費：5,000								

消費税込みの表記です。